

TROUBLESHOOTING HAIR DRYERS

Problem	Solution
Doesn't work at all	1. Refer to Troubleshooting Chart on page 205.
	2. Check thermal cutout. If faulty, service thermal cutout.
Fan doesn't work on all settings	1. Check fan switch. If faulty, service switch.
Heat doesn't work on all settings	1. Check heat switch. If faulty, service switch.
Fan works, but heat doesn't	1. Check heat switch. If faulty, service switch.
	2. Check elements. If faulty, service elements.
Heat works, but fan doesn't	1. Check fan-speed switch. If faulty, service switch.
	2. Check fan. If faulty, service fan.