

TROUBLESHOOTING FOOD MIXERS

Problem	Solution
Doesn't work at all	1. Refer to Troubleshooting Chart on page 205.
	2. Check switch. If faulty, service switch.
	3. Check motor fuse. If defective, replace fuse.
Mixer doesn't function at all speeds	1. Check speed control. If faulty, service or replace.
Motor hums, but beaters don't turn	1. Check motor. If seized, replace.
Mixer vibrates excessively	1. Check beaters. If shafts are bent or ends are worn, replace beaters.
	2. Check gears. If broken or misaligned, service gears.
	3. Check motor. If shaft is bent or motor is sparking, replace motor.